Coleman

exponent™

inyo™ solo

part number 9810-805

POLE ASSEMBLY PART

Main Tent Pole
Part No. 9810-205

Tent Pole-Foot
Part No. 9810-125

Rainfly
Part No. 9810-105



1 Layout & Positioning of Tent, Pole Assembly

- Layout and position tent with doors facing desired direction. (illus. 1)
- For best results in windy conditions position end of tent into the wind.
- Stake down tent corners using the stake loops. Keep the floor taut. Unzip doors. (illus. 2)
- Assemble Frame Poles by interlocking shock-corded sections to form one long and one short "U" shaped pole.
- Insert the longer pole through the pole sleeve at the head of the tent and the shorter pole into the sleeve at the foot of the tent. The red side of the pole should be on the side of the pole sleeve with the red trim and red frame clips. (illus. 1)



illus. 1



illus. 2
Tent stake through Loop

2 Connect Frame to Tent

- Insert one Pole Tip into grommet on stake loop located on the side of the tent.(illus. 3)
- Go to opposite end of pole and gradually apply pressure to the pole forming an arch until you are able to insert the pole tip into the grommet. (illus. 3 & 4)
- Attach Frame Clips on each side of tent. (illus. 5)



illus.4
Tent completely set up and staked out.



illus.3
Insert Pole Tip into grommet

illus. 5
Frame Clips

3 Attach Rainfly

- Layout the Rainfly and locate the logo (illus.6)
- Drape Rainfly over tent frame, the logo should be on the side of the tent without the door. (illus. 7)
- Attach frame Ties on underside of Rainfly to long tent pole (3).
- Connect the clips on the rainfly (found at the Rainfly corners) to the stake loops at the corners of the tent. (illus. 7 & 8)
- Stake out Rainfly at the front rear and on each side of the zippered door/vestibule. Pull stake loops out away from tent until Rainfly is taut. (illus.7)
- Stake out Guyline.



illus. 6
Rainfly shown with clips


Attach Frame Ties on Underside of Rainfly to Frame
Guyline
Vestibule Door Rolls up and attaches with toggle & loop for easy access or added ventilation
Rainfly stake loop

illus. 7
Completed tent with Rainfly. Note where Rainfly hooks attach and where to stake out rainfly

illus. 8
Rainfly clips to tent stake loop

Things You Should Know

- Under certain conditions (cold weather, high humidity, etc.) condensation will form on the inside surfaces of your tent. Condensation is caused by water vapor from your breath, perspiration, or any wet clothing inside your tent. It is NOT LEAKAGE through the tent fabric. It can be minimized by removing wet clothing from your tent and by providing good ventilation through the tent.
- Seam sealer has not been provided with your tent. It is necessary and we recommend seam sealing your tent prior to camping. Seam sealer may be purchased through your local retailer or at your local sporting goods store.
- Never store tent, even for a short period of time, without drying it thoroughly and brushing off caked dirt. Do not pack stakes or poles inside your tent. Use separate storage bag.
- STAKES SHOULD BE REMOVED BY PULLING ON THE STAKE ITSELF. NEVER PULL ON THE TENT FABRIC OR TENT STAKE LOOP TO REMOVE STAKE.
- TENT POLES SHOULD NOT BE LEFT TELESCOPED TOGETHER DURING STORAGE.

Coleman
exponent™

3600 N. Hydraulic • Wichita, Kansas 67219
1-800-835-3278 • www.coleman.com

Printed In China
© 2002 The Coleman Company, Inc. All Rights Reserved.